


 **Tronsmart**



MIRTUNE H1
USER MANUAL

English

Thank you for purchasing the Tronsmart Mirtune H1 Portable Outdoor Speaker. Please read the user manual before use and keep it handy for future reference. If you have any additional questions or comments, please contact us by email at: support@tronsmart.com.

Package Contents


1 x Mirtune H1 Portable Outdoor Speaker
1 x Type-C Charging Cable
1 x Warranty Card
1 x User Manual



Specifications

Model	Mirtune H1
Bluetooth Version	5.3
Bluetooth Profile	A2DP/AVRCP/HFP/HSP
Audio Codec	SBC
Bluetooth Range	Over 15m/49ft (open area)
IP Rating	IPX7
Output Power	8W
Input Power	5V/1A, via Type-C port
Frequency Range	70Hz - 20kHz
Battery	3.7V/2000mAh
Playtime(Varied by Volume Level & Audio Content)	Up to 20 Hours(On a 50% Volume)
Charging Time	2.6 Hours
Frequency Band	2402-2480MHz
Maximum Transmit Power	4dBm

Button Configuration

- ① Power On/Power Off
- ② Bluetooth Indicator
- ③ Power Indicator
- ④ Bluetooth
- ⑤ Volume -/Previous Track
- ⑥ Play/Pause
- ⑦ Volume +/Next Track
- ⑧ Type-C Charging Port






How to Operate

	Press for 2s to turn on Press for 2s to turn off Press for 10s to forced off
	Press once to turn up volume Press for 2s to skip to next track
	Press once to play/pause music Press once to answer/end a call Press for 2s to reject a call Double Press to activate voice assistant
	Press once to turn down volume Press for 2s to skip to previous track
	Press once to disconnect from device Press once to switch audio between speaker & phone dialing Press for 3s to enter stereo pairing mode Press once to exit stereo pairing mode Press for 8s to reset

How to Use


1. Turn On/Off



On	Bluetooth Indicator Flashes
Off	Bluetooth Indicator Off

2. Bluetooth Connection

Search & click 'Tronsmart Mirtune H1' to connect.



Pairing	Bluetooth Indicator Flashes
Connected	Bluetooth Indicator on

3. Disconnect from Bluetooth

Quickly connect to another device, you could press the 'Bluetooth' button once to disconnect from Bluetooth.

4. Enter/Exit Stereo Pairing Mode

Connect 2 Tronsmart Mirtune H1 speakers to enjoy powerful stereo sound.

- Turn on both speakers. Please make sure either speaker has entered pairing mode.
- Press the 'Bluetooth' Button for 3s on either speaker(Host Speaker) to enter stereo pairing mode.(Press once to exit)
- If paired successfully, the bluetooth indicator of host speaker will flash blue while vice one will stay blue.
- Search & click 'Tronsmart Mirtune H1' to connect.

5. Indicator

Power indicators flash red	Battery Low
Power indicators flash white	Charging
Power indicators stay white	Fully Charged

6. Reset

Press 'Bluetooth' button for 8s.

7. Auto Power Off

The speaker will auto-off after 30 minutes if it does not pair with any device or doesn't play any music. When on low battery, the speaker will power off automatically as well.

8. Dual Audio Modes

- Search & click "Tronsmart Mirtune H1" to connect with device A.
- Disconnect "Tronsmart Mirtune H1" from the device A (Note that do not clear the pairing record on the device).
- Tronsmart Mirtune H1 will re-enter pairing mode.
- Search & click "Tronsmart Mirtune H1" to connect with the device B.
- Click "Tronsmart Mirtune H1" on device A to connect.

9. Tronsmart App

Download 'Tronsmart App' via Google Play or App Store.



Apple & the Apple logo are trademarks of Apple Inc.



Google Play & the Google Play logo are trademarks of Google Inc.

How to Connect Tronsmart App?

- Turn on Bluetooth setting on your device, search & click 'Tronsmart Mirtune H1' to connect.
- Open 'Tronsmart' App & allow to access Bluetooth on your device.
- Slide to find out 'Mirtune H1' & click to connect.
- If connected successfully, you could customize Equalizers, etc.

Care & Maintenance

- Do not use any form of detergents or cleaning material to clean the product as any type of chemical may make this device unusable.
- Do not disassemble this product. It contains no user serviceable parts.
- Do not drop or jump on it and treat it with care for the best performance.
- Keep the product in a dry location. Dust, dirt & moisture from humidity can accumulate on the body of the product if kept at an unfriendly place.
- Do not dispose this product in fire or batteries may explode or leak.

Warranty Information

Your 'Tronsmart Mirtune H1 Portable Outdoor Speaker', is warranted to the original owner for 12 months from the date of purchase against defects in material and workmanship under normal use and service. Tronsmart is not responsible for the accidental use of this product and its liability will not exceed the purchase price of the product. If you have any problems while using the product, please do not hesitate to contact our customer support team at support@tronsmart.com.

FCC Statement

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: 1) this device may not cause harmful interference, and 2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

RF warning statement:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.



Shenzhen Geekbuy E-commerce Co.,Ltd.

Warehouse 101H, No.49 South WuHe Avenue, Wuhe Community,

BanTian Street, LongGang District, ShenZhen, China

Email: support@tronsmart.com


800-270-1082 (USA & Canada)

+86-755-23603740 (Global)

FCC ID: 2AV3Z-MIRTUNEH1



R-R-sF9-MIRTUNEH1



www.tronsmart.com

Made in China

